iRODS

More Transport, Please!

Kory Draughn
Software Developer
iRODS Consortium

June 9-12, 2020 iRODS User Group Meeting 2020 Virtual Event

The Interface



```
namespace irods::experimental::io
       template <typename CharT, typename Traits>
       class transport
       public:
           virtual ~transport();
           virtual auto open(path, openmode) -> bool;
10
           virtual auto open(path, replica number, openmode) -> bool;
11
12
           virtual auto open(path, resource name, openmode) -> bool;
13
14
           virtual auto close() -> bool;
15
16
           virtual auto send(buffer, buffer size) -> streamsize;
17
18
           virtual auto receive(buffer, buffer size) -> streamsize;
19
20
           virtual auto seekpos(offset, seekdir) -> pos type;
21
22
23
           virtual auto is open() -> bool;
24
25
           virtual auto file descriptor() -> int;
26
       };
27 }
```



It enables wizardly things!

For example:

- Compression
- Encryption
- Statistics / Diagnostics
- New Protocol Support (e.g. RDMA)

And more ...

Example: Compression w/ Snappy!



From snappy_transport.hpp

```
6 auto send(char type* buffer, streamsize buffer size) -> streamsize override
       auto output length = snappy max compressed length( buffer size);
       std::vector<char> output(output length);
       snappy compress( buffer, buffer size, output.data(), &output length);
       return tp ->send(output.data(), output length);
14 auto receive(char type* buffer, streamsize buffer size) -> streamsize override
       const auto bytes read = tp ->receive( buffer, buffer size);
       if (snappy validate compressed buffer( buffer, bytes read) == SNAPPY OK) {
           std::size t output length;
           snappy uncompressed length( buffer, bytes read, &output length);
           std::vector<char type> compressed(bytes read);
           std::copy( buffer, buffer + bytes read, std::begin(compressed));
           snappy uncompress(compressed.data(), compressed.size(), buffer, &output length);
           return output length;
       return bytes read;
31 }
```





```
1 #include <irods/dstream.hpp>
 2 #include <irods/transport/default transport.hpp>
   int main()
       namespace io = irods::experimental::io;
       auto large buffer = read a whole lot of data();
10
11
12
       io::client::default transport dtp{conn};
13
14
       if (io::odstream out{dtp, "/tempZone/home/rods/foo.txt"}; out) {
15
           out.write(large buffer.data(), large buffer.size());
16
17
18
19
       io::client::snappy transport stp{conn, dtp};
20
21
22
       if (io::odstream out{stp, "/tempZone/home/rods/foo.txt"}; out) {
23
           out.write(large buffer.data(), large buffer.size());
24
25 }
```

Example: Compression w/ Snappy! (cont.)



Using tc to emulate a delay of 200ms RTT.

- File Size = 72971843 bytes (73MB)
- Buffer Size = 4000000 bytes (4MB)
- Single Stream Object
- Custom iRODS server supporting compression and decompression
- Write Speeds roughly 40% faster
- Read Speeds roughly 36% faster

Results vary depending on the network, file size, and buffer size.